



Fitting cross is located 4mm above lens Prism Reference Point.

\*○= Regular (18 mm), ○= Short (15 mm)  
 \*Minimum fitting height